Sandwich Maker

Model CE093SM

PLACE PICTURE HERE

INSTRUCTION MANUAL

SAVE THESE INSTRUCTIONS

Dear Valued Customer

Thank you for purchasing a *CASCADE* appliance.

We understand the importance of your purchasing decision, and appreciate your final choice to introduce this *CASCADE* product into your home.

Your *CASCADE* appliance is recognised as a quality product at an affordable price, and is proudly supported by our after sales service team. We encourage you and your friends to choose from the range of *CASCADE* appliances available exclusively to The Warehouse.

TECHNICAL INFORMATION

Please make sure that your house installation voltage corresponds to the voltage marked on the unit.

Mains supply:	230-240V ~ 50 Hz – AC only
Rated Power:	750 watts

BEFORE FIRST USE

1. Your CASCADE Sandwich Maker has left the factory in good working order in this carton for your protection. Should the carton be damaged or if the product is dropped, damaged, has a malfunction in any way, or if the flexible cord is damaged, immediately contact your retailer for replacement or repair.
2. Carefully unpack your CASCADE appliance. Make sure you do not discard any packaging material until all parts of the appliance have been found.
3. Carefully wipe the exterior of the appliance with a damp cloth to remove any dust that may have accumulated. Dry with a dry towel. Do not use abrasive cleaners.
   WARNING Do not immerse in water or any other liquids.
4. Wash the accessories in warm soapy water. Dry with a dry towel.
5. The appliance is now ready for operation.

OPERATION

- Before using the appliance for the first time, or after long periods of storage, clean the appliance thoroughly. (See BEFORE FIRST USE.)
- Always place the appliance on a flat, clean and non-slippery surface before operating it.
- Always place the appliance on a heat resistant surface as the appliance reaches high temperatures.
- WARNING always leave a gap of approximately 20 cm around the exterior of appliance. Never use near curtains, walls, under cupboards or other flammable materials.
- Plug the power cord into a suitable mains outlet corresponding to the supply requirements of your appliance.
  Mains supply: 230-240V ~50Hz – AC only
- Your CASCADE sandwich maker is now ready for use.
- Plug the sandwich maker into an AC power outlet and ensure that the indicator light comes on indicating that power is available.
- Close the sandwich maker and prepare sandwich while the appliance is heating.
- When the sandwich maker is ready (after about 5 minutes) the indicator light will go off. The green indicator will light to indicate the appliance is ready.
- Fully open the sandwich maker, place a slice of bread in the bottom half with the buttered side against the plate.
- Place filling on top of bread. Keep filling about 10mm clear of edge of bread so that the out side edges can be sealed.
- Place top slice of bread with the buttered side up and carefully close the two parts of the appliance. Do not force the appliance shut as steam may be ejected from between the plates risking burning of fingers.
- NOTE: During toasting the indicator lights will cycle "on" and "off" while the thermostat keeps the sandwich maker at the correct operating temperature.
- Your sandwich will take between 2-5 minutes to cook depending on filling and required result.
- Open the sandwich maker and remove the sandwich. Use a plastic or wooden spatula. Never use a metal knife as this may damage the non-stick coating.
- Prepare further sandwiches if required whilst one is cooking. After use, remove the plug from the wall socket.
- NOTE The first time you use your appliance, there may be a small amount of smoke and smell. This is normal**.** It is due to a protective coating, placed on the heating elements, to protect the heating elements during shipping.
- WARNING Do not touch hot surfaces.

CLEANING AND CARING

- After use and before cleaning, remove plug, wait for sandwich maker to cool.
- Wipe the inside and edges of the plate with absorbent paper toweling or a soft cloth.
- Should filling be difficult to remove, pour a little cooking oil onto the plate and wipe off after 5 minutes, when the food has softened.

- Wipe the outside with only a slightly moistened cloth ensuring that no moisture, oil or grease enter the appliance.
- Do not clean the inside or outside with any abrasive scouring pad or steel wool as this will damage the finish.

TO STORE: Do not store until appliance has completely cooled. Store in its box or in a dry place. Store the cord loosely coiled. Never wrap it tightly around the unit. Do not put any stress on cord where it enters the appliance as this may cause the cord to fray and possibly break.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Carefully read these instructions before using your appliance.
2. CAUTION Keep out of reach of children. This appliance is not intended for use by young children or infirm persons. Young children must be supervised to ensure that they do not play with the appliance.
3. Safely dispose of plastic bags and other components of the packaging. They may be potentially dangerous to children.
4. VERY IMPORTANT Do not immerse in water or other liquids or use near washbasins or sinks. Ensure that the appliance does not get wet (water splashes etc.) and do not use it with wet hands.
5. Unplug from mains outlet when appliance is not in use, before attaching or removing accessories, and before cleaning.
6. An appliance dropped or damaged should not be used until examined by a service engineer.
7. Do not permit the mains lead to come in contact with hot objects.
8. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
9. Use this appliance only for its intended use. Use only genuine attachments supplied by an authorised Service-Dealer.
10. The appliance should not be used outdoors, placed near a hot gas or electrical burner or placed in a heated oven.
11. Do not let the cord hang over edge of table or counter.
12. WARNING An appliance should never be left unattended when plugged in.
13. This appliance is intended for household use only and not for commercial or industrial use.
14. WARNING Do not touch hot surfaces.
15. WARNING Hot steam may be ejected when opening the lid.
16. WARNING Always place the appliance on a heat resistant surface, as the body will reach high temperatures.
17. WARNING Ensure adequate ventilation, keep an open space of approximately 20 cm all around the appliance.
18. WARNING Do not use the appliance near flammable materials such as curtains, walls or under cupboards.
19. If appliance is to be used by a third party, please supply the instruction manual with it.
20. No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

CAUTION

Do not attempt to service this appliance yourself. Refer servicing to qualified service personnel.

SANDWICH MAKER RECIPES

Bacon, Lettuce and Tomato

4 Slices White Bread
1 Tomato, Sliced
Few Pieces of Lettuce
4 Thin Slices Bacon
Softened Butter

Spread one side of the bread with softened butter, put two slices on the sandwich maker, buttered side down. Arrange the tomato, chopped lettuce and grilled bacon on top. Cover with the other slices of bread, buttered side up. Toast for four minutes.

Scrambled Eggs and Bacon

4 Thin Slices Bacon
4 Slices White Bread
Softened Butter
2 Tablespoons Milk
Salt and Pepper
1 Large Egg
½ Oz Butter

Grill the Bacon and cut into pieces. Scramble the egg with butter, milk and seasoning until lightly set. Spread one side of the bread with softened butter, put two slices on the sandwich maker, buttered side down. Arrange the scrambled egg and bacon on top and cover with the other slices of bread, buttered side up. Toast for four minutes.

Warranty Card

This product is guaranteed against faulty materials and workmanship for a period of two years from the date of purchase with proof of purchase. The obligation to the purchaser under this warranty is limited to servicing the unit and replacing defective parts or refund when the product is returned freight prepaid to the retailer with proof of purchase. This warranty becomes void if the product has been tampered with, damaged by accident, damaged in any other way by improper use or has been purchased second hand. All production orders have quality inspections. In the unlikely event of a deficiency, please contact the retailer from which this product was purchased.

WARRANTY FOR APPLIANCES USED COMMERCIALLY LIMITED TO 90 DAYS

Type of Appliance: _____

Model No.: _____ Purchase Date: _____

Product Purchased From: _____

_____

Your Name: _____

Address: _____

_____ Phone Number: _____

IMPORTANT!

Please retain this warranty card along with your purchase receipt. Please do not post to the retailer. If service or a warranty claim is required, both of these documents are to be returned with the appliance to your retailer, otherwise a fee may be charged or warranty declined. For technical help contact the helpline.

Technical Assistance Helpline

New Zealand call Toll Free 0800-898580
Australia call Toll Free 1-800-858011
Email service@orientalpacific.com